



#600 Water Stop Product Data Sheet

Reactivity

Please note that times can be adjusted for specific applications.

Hand Pour:

Cream: 45 seconds
Rise: 45 seconds
Tack Free: 60 seconds

Machine Pour:

Cream: 10 seconds
Rise: 15 seconds
Tack Free: 15 seconds

Before using read and follow the SDS guidelines precautions and first aid directions carefully.

Use this reference as a guide only. The information is believed to be reliable, but no guarantee is made nor do we assume liability in connection with its use.

THE MANUFACTURER RESERVES THE RIGHT TO AMEND, REVISE, AND/OR UPDATE INFORMATION CONTAINED IN THIS DOCUMENT.